

Tideflex® • Installation onto Headwall • TF-2 with Thimble Plate



Step #1

The headwall should be clean, and the surrounding area cleared of debris.



Step #2

The pre-drilled thimble plate is used as a template to drill the headwall. Anchor bolts are then set.



Step #3

A large rubber gasket is used behind the plate to ensure a good seal. Stainless Steel nuts are used to secure the plate to the headwall.



Step #4

The Tideflex® TF-2 is slipped over the thimble plate and secured with a stainless steel clamp.